

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Dep Johnson AGENCY LPCSO  
DATE 6-12-16 TIME 1356  
INTOXILYZER SERIAL # 80-001200 LOCATION COUNTY PARK

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
4. Air blank completed.
5. Calibration check completed. Test results 0.099 AC.
6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE \_\_\_\_\_

INTOXILYZER 8000

Location: QTZ 103/LPCS BACK UP

Serial Number: 80-001200

Core Version: 8105.48

06/12/2016

13:56:37

-----  
Standard Lot#: 08915100A2

Last Changed By: R. ROSADO #557  
-----

QAS: M. JOHNSON #531

LA PAZ CSO  
-----

Operator: M. JOHNSON #531

LA PAZ CSO  
-----

Test	g/210L	Time
Air Blank	0.000	13:57:09
0.100 Cal Check	0.099	13:57:29
Air Blank	0.000	13:57:59

Preventative Maintenance

Performed -- Timer Reset